

## Matching a Tri-Tronics EXP Collar or ViceBreaker® Collar to Your System



### Please read all steps before starting.

- Install strap of the desired color on the new collar and charge new receiver for two hours. (For ViceBreaker® H2 install the leather strap.)
- Set transmitter dog/horse selection switch to the color of the strap (colored sleeve on ViceBreaker® H2).
- Set transmitter intensity dial to a number, not a letter.
- Turn the collar on.
- Press and hold collar on/off button, then press and hold a “continuous” transmitter button (low or medium stimulation button on ViceBreaker® H2). Hold both buttons down for about 5 seconds – until you hear two quick beeps (ignore the long beep that sounds right away). Release both buttons.
- The collar will now be set to match your transmitter, and will be turned off.
- Check for a successful match by turning the collar back on and pressing a “continuous” transmitter button. The collar light will turn on. If you are not planning to use the unit now, turn the collar off after testing.

If the transmitter does not operate the new collar, try the procedure again. If you are still having trouble please call our Customer Service Department at 1-800-456-4343 for help.

**Note for dog collars:** Two additional colored straps were included with your original purchase.

**Note for Classic 70 G2 EXP or Trashbreaker G2 EXP.** When adding a receiver for dogs 1 – 3, use the button that matches the strap color and place the dog selection switch in the UP position. When adding a receiver for dogs 4 – 6, use the button inside the colored circle that matches the strap color and place the dog selection switch in the DOWN position.

If you are adding receivers 4 – 6 to these models, a package of orange, green and yellow straps is available from Tri-Tronics or your favorite dealer.

*See other side for compatible models.*